

THIBAUT

Instructions for hanging Thibaut Twilight Mural

PRE-TRIMMED, NONWOVEN, STRIPPABLE, DIGITALLY PRINTED

Twilight Mural is a captivating and awe-inspiring design which will add sophistication to any environment. This fine handcrafted mural will reward you with many years of complete satisfaction. For the best results, we recommend a professional wallcovering installer hang this mural.

Specifications: Mural consists of 4 trimmed panels; each panel is 27 inches wide x 10 feet high for a total of 90 square feet. Panels are to be separated at the cut line indications between panels. Refer to the diagram on the mural itself for exact panel rotation. Panel 4 can be matched to panel 1 to create a continuous mural.

Before you start to hang: Examine goods to make certain pattern and color is accurate and as ordered. Have all associated products in your possession to insure correct color match. Install the mural under adequate lighting and heated conditions that will exist when space is occupied.

Important: Once installation has commenced if you notice any defects in the material, STOP work, and notify your supplier. **NO ALLOWANCES FOR LABOR OR MATERIAL WILL BE MADE PAST THIS POINT.** Product does not change appearance from wet to dry. As a gesture of goodwill Thibaut will reimburse \$200.00 to any professional installer that adheres to the conditions noted above.

Preparation: Our quality mural may be applied to any smooth, clean, dry surface. Remove old wallcovering completely and remove remaining adhesive. Cracks should be filled with a spackling compound and sanded smooth. Glossy or enamel walls should be lightly sanded and washed with common household detergent. Prime all walls with a Universal Pre-Wallcovering primer.

Mildew: Mold and mildew require moisture in order to grow, therefore it is important that any excessive moisture in the wall be corrected prior to installation. On old walls where mold spores may be present, they should be washed with a detergent solution or cleaned using a vacuum with a HEPA filter. This should be followed by treating with a chlorine bleach solution of 1 cup bleach to 4 quarts water to kill any remaining spores. Rinse clean and dry.

Adhesives: This wallcovering requires the use of a heavy duty clear premixed vinyl adhesive. Dilution of the adhesive should be avoided.

Application: Hang the first strip parallel to a plumb line. Cut strips a few inches longer than required to allow for trimming at ceiling and baseboard. Be sure to match the design and do not overlap seams.

Apply the recommended adhesive to the back of the first strip using a paint roller. Work the adhesive to cover the back completely, especially near the edges. Fold or "book" each end toward the middle, pasted sides together, aligning the edges carefully so they do not dry out. Fold or roll the booked strip loosely and set aside for three to five minutes. Unfold your first strip halfway and install at the plumb line, unfold the bottom of the strip, and keep aligned to the plumb line. Using a smoothing brush or a plastic smoothing blade to remove air pockets or paste lumps working toward the uncovered wall assuring complete adhesion. With clean water and a sponge, clean off any excessive adhesive on the face of the wallcovering, paste residue may cause damage to the print surface. Trim at ceiling, baseboard, windows, and doors with a single edge razor blade changing razor blades often.

continues to next page →

